

AmmoBot™ Primer Pocket Probe Setup Instructions.

Warning: The probe pin is under spring tension! If you loosen the set screw without holding the pin it will fly across the room in spectacular fashion.

1. Place unprimed piece of brass of the appropriate size into the shell plate.
 - a. Use large primer pocket for large pin, small primer pocket for small pin
2. Rotate casing to the swage station.
3. Lower arm on the press to lowest position
4. Loosen the set screw in the thumb tab (see picture) to allow probe pin to slip into the primer pocket.
5. Push up on the thumb tab with one hand until it stops moving and snug the set screw with the other. Please be sure not to over-tighten.
6. Place an unprimed piece of brass of the opposite size in the shell plate and rotate to the swage position
7. Lower the handle and make sure the switch is actuated
8. Wipe hands on pants

